

Please confirm your Nabu's power connector before connecting any cards, some systems have been modified at the factory.

1. If you are using a floppy controller only, no modifications need to be made.
2. Factory modification-
 - a. remove molex power connector from motherboard
 - b. cut gnd trace between pin 1 and pin 3 top side of board
 - c. add jumper wire between blue -12 power wire and pin 3 of molex connector on bottom of board
 - d. bridge pin 1 and 2 of molex connector on bottom of board.
3. alternate modification-
 - a. add jumper wire between blue -12 power wire and pin 2 of molex connector on bottom of board
 - b. swap pin 2 and 3 on female molex connector on floppy interface cable or what ever card is plugged into motherboard, all remaining cards need no modifications and daisy chain from the first card.

Nabu Power connector			Serial/Floppy card Female Molex power connector		
Back of Unit					
pin 1	x	Gnd	pin 1	x	Gnd
pin 2	x	NC	pin 2	x	Gnd
pin 3	x	Gnd	pin 3	x	-12
pin 4	x	+5	pin 4	x	+5
pin 5	x	+12	pin 5	x	+12
blue wire		-12			

After Factory Modifications

pin 1	x	Gnd	pin 1	x	Gnd
pin 2	x	Gnd	pin 2	x	Gnd
pin 3	x	-12	pin 3	x	-12
pin 4	x	+5	pin 4	x	+5
pin 5	x	+12	pin 5	x	+12

After Alternate Modification

Female molex connector to motherboard

pin 1	x	Gnd	pin 1	x	Gnd
pin 2	x	-12	pin 2	x	-12
pin 3	x	Gnd	pin 3	x	Gnd
pin 4	x	+5	pin 4	x	+5
pin 5	x	+12	pin 5	x	+12